


KG05/06/08/10/12

SOUNDKING AUDIO
WWW.SOUNDKING.COM

SOUNDKING.

SOUNDKING.





ON:

OFF:

-
-
-
-

-

-

-

-

1. : KG,

100-240 ,

SD- USB Bluetooth.
SD USB


KG

2.



- 1) 8 / 2 ;
- 2) (0-9) ;
- 3) SD- , USB Bluetooth;
- 4) (+48?) ;
- 5) DSP- 16 ;
- 6) 2 8 ;
- 7) 100-240 ;
- 8) MP3-



	10 30 , +/- 3 dB
	0,03% +4 dBu, 22 -20 , A
	: 0-9 : 20 -5
/ :	115
	10 30 , +/- 3 dB
	0,005% +4 dBu, 22 -20 , A
	: 75 dBu
	/
	10 55 , +/- 3 dB
	0,005% +4 dBu, 22 -20 , A
	1,4
	10
	10
	1
	120
HI ()	+/-15 12
MID ()	+/-15 2, 5
LOW ()	+/-15 45
	80 , 18
HI ()	+/-15 12
LOW ()	+/-15 60
DSP-	24 , 16
()	0 ,
	; -100dBu (: +4dBu)
	. +27dBu; . : +22 dBu, 1/4"
	AUX. +22 dBu
	DSP- : +22 dBu
	100-240 . 50/60 .
(. " . " . ")	KG05: 274 x 193 x 78 KG06: 330 224 92 KG08: 330 280 92 KG10: 330 336 92 KG12: 330 392 92
	KG05: 2,2 KG06: 3, 5 KG08: 4 KG 10: 4, 5 KG 12: 5, 2



1. **LINE/USB/MP3** -10/+4
2. **LINE/USB/MP3** 10
3. **USB/MP3/bluetooth**
 - High (): 12
 - Low (): 12
 - +15dB. 12
 - 15dB. 12
 - +15dB. 60
 - 15dB. 60
4. **AUX-DSP** DSP.
5. **PAN** DSP.
6. **PEAK** 3
7. **PEAK** 3
8. **MUTE** MUTE.



SD USB-

PLAY/PAUSE.

PLAY/PAUSE.



PLAY/PAUSE.

30


'001 - Silence'

(30)

- 1.
- 2.
- 3.
- 4.
- 5.



1. XLR (1-6), 2: KG06 45, 3: KG06 2, 4: KG08 100, 5: KG10-6, KG12-8
2. 1/4" TRS (/), LEFT/MONO (/), RIGHT
3. AUX- 1/4" AUX ()
4. DSP 1/4" DSP- DSP.
5. AUX RETURNS 1/4" AUX RETURN.
6. PLAYBACK RCA 3,5 CD-
7. RECORD RCA
8. MAIN MIX XLR MAIN MIX.
9. CTRL ROOM 1/4"
10. POWER
11. POWER




1. ()
2. ()
3. AUX send
4. PLAYBACK
5. CTRL RM PHONES
6. PLAYBACK
7. MAIN MIX
8. ()
9. DSP ON
10. DSP

11. PARAMETER
12. PROG RAM

Prg#	Description	Parameter 1
1		0,9 -3,5
2		1,5 -8,6
3		0,28 -0,82
4		0,36 -1,38
5		0,44 -1,54
6		0,72 -10
7		0,4 -2,3
8		0-680
9		0-680
10		0,56 -3,5
11		0,58 -6
12		0,58 -4,35
13		0,58 -11
14		0,25 -0,78
15		0,34 -2
16		0-400

13. PEAK
14. PEAK
15. MAIN MIX
16. MAIN MIX

SD/USB/B LUETOOTH



1. : SD card (SD-),
USB, bluetooth, recording ().
a) SD/USB: SD- /USB-
b) Bluetooth:
bluetooth-
c) :

2. PLAY/PAUSE.
3. STOP
4. Repeat ()
5. Previous ()
6. Next ()
7. SD-
8. USB-

- SD card/USB
Loop ()
1= ().
F=
R= ()
= ()